

Liquid Release

Liquid Release for Overlay Stamp Method

Step 1

Once the Concreation Overlay Stamping Mix or regular concrete is cured to the point where it is ready to stamp, start by spraying a section of the surface approximately 50 sq. ft. at a time with the Concreation Liquid Release where you wish to begin stamping. Spray Concreation Liquid Release at a coverage rate of 200-300 sq. ft. per gallon to completely cover the surface in a thin, even coat using a pump-up sprayer.

Step 2

After spraying a section of the surface spray the textured side of the stamps one time with the Concreation Liquid Release before laying them on the surface. Immediately place the first stamp over the Concreation Liquid Release and square with the starting edge or corner. Use the handles on the stamp to carefully set it in place. While standing on the first stamp lay the second stamp next to it and so on until all of the stamps are fit tightly together over the stamping material and Concreation Liquid Release.

Step 3

Once the stamps are in place, use your feet and/or the stamp pounder to walk or pound on the stamps to leave the desired impression. If the stamping material is soft you may not need the pounder, simply walk on the stamps with your feet. Before moving a stamp stand on one end while lifting the other end halfway off the surface to check for any bald areas. If necessary lay the stamp back down and pound again using your feet or the pounder where needed.

Step 4

After achieving the desired impression, lift each stamp straight up off the surface and move to the next area. Continue spraying the Concreation Liquid Release ahead of the stamps a section at a time and moving stamps until the entire surface is completed. If an antiqued look is desired Concreation Powder Release can be added to the Concreation Liquid Release prior to stamping. To use the Concreation Liquid Release for antiquing, mix 1-4 ounces of Concreation Powder Release, in the colour desired, to one gallon of the Concreation Liquid Release. More antiquing can be added using the same method only pooling in the Concreation Liquid Release and Concreation Powder Release mixture once the concrete has been stamped to obtain the desired look. As the stamped concrete dries and the Liquid Release evaporates, the colors of the stamped concrete and the antiquing color will fade lighter. When sealed with either Concreation

GreenSil WA, Concreation Acrylic Concrete Sealer the colors will come back to how they looked when wet. Always practice on a sample board to perfect the look you want and have it approved by the customer.

Removing The Antique Colour Where Too Heavy or Uneven Before Sealing

If the antiquing color was applied to heavy or unevenly, it should be able to be removed (before sealing) using simple green detergent and a scrub broom. Try diluting Concreation 750 Cleaner with 5 - 10 parts of water and scrubbing the surface to remove any unwanted antique color. Pressure-wash the surface to clean and rinse. For stubborn areas you may need to use Concreation 750 Cleaner undiluted. When rinsed and dry, use the method below to restore the antiquing to the surface.

Antiquing Method For Spray Top & Stamped Concrete

This method of antiquing requires using clear Concreation Liquid Release during the stamping process then coming back the next day when the stamped surface is dry to apply the antiquing. This method is easier since you do not have to stamp and antique at the same time as with the previous method.