

Parge Mix Application

SURFACE PREPARATION

1. Clean the surface with **Concreation CCI-750 Cleaner** to remove oil, grease, dirt or any other contaminants and etch the surface to provide a sufficient bond. Next, pressure wash the surface at close range using a 3000 psi pressure washer to clean and rinse. It is recommended that a neutral wash of **Concreation CCI-750 Cleaner** be used to balance the pH. See instructions for **Concreation 750 Cleaner** for more detailed directions. Shot blasting is another popular method for preparing the surface, especially for indoor jobs.
2. For a more stable installation a wire mesh can be attached to the vertical surface prior to applying **Concreation CCI-400 Parge Mix**.
3. After cleaning the surface, fix any cracks in need of repair using the **Concreation CCI-400 Crack Repair**. Refer to **Concreation CCI-400 Crack Repair** for more detailed information on the steps required for different applications. Crack repairs are not guaranteed but always recommended before resurfacing.

PRODUCT APPLICATION

1. To mix the **Concreation CCI-400 Parge Mix** start by adding 3 liters of water to a 5 gallon pail (Based on using 22.5 Kilo Bag). Slowly add the **Concreation CCI-400 Parge Mix** to the water while continuously mixing with a paddle mixing drill. Allow the mix to slag (false set) for 10 minutes. If the mix is too dry more water can be added, DO NOT ADD water if **Concreation CCI-400 Parge Mix** begins to SET, this may affect bonding ability and will affect the final colour.
2. The best method to clean the surface on outdoor jobs is to pressure wash in which case no detergent will be needed. For small jobs or indoor jobs where a water hose will be used to rinse the surface, it will be necessary to first scrub the surface with a mild detergent such as **Concreation 750 Cleaner**. Use a soft-medium bristled broom to lightly scrub over the stamped

surface then immediately rinse the surface clean and wet/dry vacuum before the detergent has a chance to dry.

COLOUR NOTES

Concreation CCI-400 Parge Mix is available in 4 Standard Colours: Beige, Grey, Red, and White.

Additional colours can be obtained by adding **Concreation CCI-200 Colour Packs** to the Grey or White Parge Mix.